V430
Studio desk

CARE INSTRUCTIONS
We recommend caring for the Vipp Studio desk to ensure its longlasting appeal and appearance.

GENERAL CARE
Frame
Keep the frame surfaces clean and dry. Vipp products with powder-coated surfaces should be cleaned with a lint-free, soft cloth and, if stained, with a bit of water warm water and mild cleaning agent. Finish by wiping down the surface with a dry cloth. For polished surfaces, use a polishing cloth to recall the shining effect. Do not use coarse cloths or detergents that may scratch the polished surface.

WARRANTY
Vipp offers warranty on your product according to national laws and regulations. The warranty does not cover defects or damage caused directly or indirectly by misuse or poor maintenance, violence or manipulation. In case of a defective product, please contact your place of purchase.

For questions regarding your Vipp product:
Europe | info@vipp.com | +45 4588 8800
US | vippusa@vipp.com | +1 (917) 580 2148

1 x large allen key | 1 x small allen key | 8 x large screw | 4 x small screw

ASSEMBLY GUIDE
Please follow the guide to ensure correct assembly. If you experience problems, please do not hesitate to contact **Customer Service at info@vipp.com.**

A) Insert the two preassembled sides into the three profiles.
B) Fasten the 8 large screws in the two upper profiles.
C) Fasten the 4 small screws in the back profile. Make sure to turn the profile with holes facing downwards and insert the screws from the bottom and up.
D) Carefully place the table top on the frame.